

SIMPLE ASSEMBLY BASE INSTRUCTION GUIDE

- 1.) Screw alignment bolt into base alignment hole just enough to barely penetrate under side of base.
- 2.) Turn base upside down to assemble.
- 3.) Place base with alignment bolt onto column with alignment hole.
- 4.) Tightly screw 3/4" bolt into center hole of base and column.
- 5.) While upside down, attach assembled base to table top with wood screws.

INCLUDED PARTS:

- (1) COLUMN WITH WELDED SPIDER
- (1) BASE (X, T, ROUND) W/ GLIDES ATTACHED
- (1) HEAVY-DUTY 3/4" BOLT 
- (1) ALIGNMENT BOLT 

